RETROFITTING Earth Fault Protection Overcurrent with or without Directional Criteria



NPIHD800R (R2 case) is dedicated to the refurbishment of 7000 series (R2 case) of CEE earth fault overcurrent and directional relay providing the detection of zero-sequence currents of medium and high voltage electrical networks. This numerical and multi-function relay supervises in particular the phase to earth faults and the good operation of the circuit breaker and its trip circuit.

NP800R relays provide monitoring, measurement and recording of the electrical quantities of the network.

The relays can be set locally, using either the keypad and display or the RS232 port, or remotely using the RS485 port.

Two mountings are available, Flush Rear Connection (**EDPAR**) or Projecting Rear Connection (**SDPAR**). A blank cover R1, provide in option, can improve mechanical installation (replacement of CEE case R3 by a NPIHD800R).

Setting, reading, measurement and recording are all available locally or remotely.



Minimises retrofitting man-hours

Maximises preservation of existing installation

Simplifies and reduces recommissioning time

Minimises retrofitting costs

NPIHD800R - EDPAR

Protection functions

- Earth fault with 2 thresholds [50N] [51N]
- Earth directional [67N]
- Load reclosing function
- Logical selectivity

Additional functions

- Latching of the output contacts [86]
- Trip circuit supervision of the breaker [74TC]
- Breaker failure [50N_BF]
- Load shedding Load Restoration, remote control

CHARACTERISTICS NPIHD800R

Auxiliary Supply

- Auxiliary supply ranges
- Typical burden
- Memory backup

Analogue inputs

• Earth current CT

- Recommended CTs
- Earth current from Ring CT 100/1 or Ring CT 1500/1 and BA800
- VT nominal value

• Frequency (50Hz or 60Hz)

Digital inputs (4)

- Polarizing voltage
- Level 0
- Level 1
- Operating of the input by level 1 or 0
- Burden

Output Relays (3 + 1 WD)

• Relays A, B: (signalling, Shunt Opening Release)

- Relays C & WD: (control, WD: Watchdog) (C: programmable for CB Shunt Opening Release or Under Voltage Release)
- Relays pulse, except WD
- Assignment of name to the output maximum of 16 characters

Earth fault function [51N] [50N]

- Operating range Io> Io>>
- Thresholds accuracy
- Reset percentage on the operating level
- Instantaneous operating time
- Definite time delay
- Accuracy of time delays
- Curves [51N] Io>
- Curves accuracy and type

Earth directional function [67N]

- Operating principle
- · Measurement of residual voltage Vr
- Polarization threshold
- · Operating mode according to the polarization voltage
- Angle measurement Vp/Io
- \bullet Setting of characteristic angle α
- Inhibition of the function

19 to 70 - 85 to 255 / Vdc or Vac 50 or 60 Hz 6 W (DC), 6 VA (AC) 72 hours

 $In_0 1 or 5 A$ measurement from 0.005 to 2.4 In₀ burden at $In_0 < 0.5 \text{ VA}$ continuous rating 1 In₀, short duration withstand 40 In₀ / 1s CT setting: primary value from 1 A to 10 kA

display of primary current from 0 to 6.5 kA

5VA 5P20

measurement from 0.1 to 48 A primary

Un: 33 to 120 V

functionalities

input impedance > 80 k Ω

Continuous rating 240 V, short duration withstand 275V - 1 min

measurement from 1 to 240 V

VT setting: primary value from 220 V to 250 kV measurement: 45 to 55 Hz or 55 to 65 Hz

20 to 70 Vdc for 19 to 70 V auxiliary supply range 37 to 140 Vdc for 85 to 255 V auxiliary supply range < 10Vdc range 19 to 70 V - < 33Vdc range 85 to 255 V > 20Vdc range 19 to 70 V - > 37Vdc range 85 to 255 V programmable < 15 mA

double contact NO, permanent current 8 A closing capacity 12 A / 4 s short-circuit current withstand 100 A / 30 ms breaking capacity DC with L/R = 40 ms: 50W breaking capacity AC with $\cos \varphi = 0.4$: 1250 VA changeover contact, permanent current 10 A closing capacity 15 A / 4 s short-circuit current withstand 250 A / 30 ms breaking capacity DC with L/R = 40 ms: 50W breaking capacity AC with $\cos \varphi = 0.4$: 1250 VA adjustable from 100 to 500 ms by the setting software capital letters or digits

0.03 to 2.4 In₀ / CT - 0.6 to 48 A / ring CT 1% typical, 2% max from 0.05 to 0.4 In_0 / CT 3% typ., 5% max from 0.03 to 0.05 $\rm In_0$ and 0.4 to 2.4 $\rm In_0$ / CT 5% from 0.6 to 48 A / ring CT 95% 60 ms including trip for $I \ge 2$ Is 40 ms to 300 s: [51N] Io> [50N] Io>> ± 2% or 20 ms IEC 60255-3, ANSI IEEE

class 5 - Time Multiplier Setting: 0.03 to 3 s, type: see

assignment of a directional criteria to the functions [50N] [51N] measured or calculated, to be defined at the order 3% to 20% Un, step of 1 %, accuracy \pm 5 % or 1 V programmable: blocking or permission (tripping by functions [50N] [51N]) -180° to + 180°, accuracy \pm 5% -180° to + 180°, step of 1°, accuracy \pm 5% programmable: yes or no; by digital input or by the communication

CHARACTERISTICS NPIHD800R

Load reclosing function

Application threshold adjustment [50N] [51N]
 Operating principle function activation by digital input

Ratio « K » of reclosing time
Accuracy
50 to 200%
± 5 %

• Reclosing time 40 ms to 300s, \pm 2% or 20 ms

Latching of the output contacts [86]

• Latching of output relays A, B, C

Reset digital input, digital communication or local MMI

Trip circuit supervision and breaker failure [74TC] [50N_BF]

Trip circuit supervision [74TC] requires one or two digital inputs (see application guide)
 Operating time (in faulty condition)
 Failure threshold [50N_BF] 0.5% to 3% In₀, step of 0.1 In₀
 Breaker failure time delay 60 to 1000 ms, step of 10 ms

Logical selectivity

• Application on radial network number of relays too important to allow the use of time

co-ordinatio

• Operating principle additional time added to the functions [50N] [51N]

• Additional time delay [51N] 60 ms to 120s, \pm 2% or 20 ms • Additional time delay [50N] 60 ms to 3s, \pm 2% or 20 ms • Operating mode of digital inputs negative or positive true-data mode

Digital inputs assignment

By setting software
 Setting table selection set 1 – set 2

• Disturbance recording order

Logical selectivity

Interlock o/oInterlock c/o

Control mode
 dedicated to remote control, local / remote

Closing modeReset [86] functionTrip circuit supervision

E [86] functionacknowledgment of the selected output(s)circuit supervision[74TC] function

Trip circuit supervision
 CB trip external order

• CB trip external order function [74TC] blocked if external trip order

• Input – output programmable functions

User programmable functions (digital inputs - digital outputs)

• Status of the function in or out of service, by local MMI or by the setting software

Tripping mode or report
 Operating and release time delays
 report: for time stamping and event recorder tripping mode: 40 ms to 300 s

 Assignment of name to the function, maximum of 14 characters

• Assignment of one or more output relays (alarm or trip) by local MMI or by the setting software A, B, C

Counters

• Operation number of circuit breaker 0 to 10 000

Load shedding - Load Restoration, remote control

Load shedding level 1 to 6
Time delay before reclosing 1 to 120 s, ± 2%

• Reclosing pulse 100 to 500 ms (remote control)

 Output relays assigned programmable by local MMI or by setting software A, B, C

Digital outputs assignment

• By local MMI or by setting software

Signalling LEDs assignment

• By setting software

Man Machine Interface

Relay display
 Language
 2 lines of 16 characters
 French, English, Spanish, Italian

• Configuration and operating software Windows® 2000, XP, Vista and 7 compatible

Language French, English, Spanish, Italian

MODBUS® Communication

• Transmission asynchronous series, 2 wires

• Interface RS 485

• Transmission speed 300 to 115 200 bauds

Disturbance recording

Number of recordingsTotal duration52 periods per recording

• Pre fault time adjustable from 0 to 52 cycles

CHARACTERISTICS NPIHD800R

Presentation

• Height

• Width

• Brackets 19" rack mounting

Case (see drawing D40037)

• EDPAR

H, W, D (case & base)
H, W (front face dimensions)

• SDPAR

H, W, D (case & base)
H, W (front face dimensions)

Weight

Connection - codification

• NPIHD800R

Ring CT

• BA800

4U

case R2

see diagram 9954 (7000 series rack definition table)

172 x 83 x 222 mm

217 x 98 mm

172 x 83 x 227 mm


172 x 83 mm

3.5 kg


See diagram S39965 See diagram 142941 See diagram 38766


SMARTsoft

SMARTsoft, integrated software for the Industry, Railway and Transmission ranges, helps the User get the best from NP800R series relays.









Functionalities


- 2 ranges of auxiliary supply
- Storage of the lack and the restoration of the auxiliary voltage (time stamped events)
- Configuration and parameter setting by local MMI or off-line / on-line PC
- Measurement of electrical quantities:
 Display expressed in primary values
 Instantaneous, integrated and maximum values of earth currents
 Residual voltage value
- · Instantaneous alarm threshold
- Definite time tripping
- Dependent time tripping according to inverse/very inverse/extremely inverse IEC 60255-3 curves
- Tripping according to RI curve (electromechanical)
- Tripping according to moderately inverse/very inverse/extremely inverse ANSI /IEEE curves
- 2 setting groups, locally or remotely selectable
- CB Monitoring: interlocks discrepancy, local or remote control of closing / tripping
- Circuit breaker maintenance: counter of operation number, over operation alarm
- Monitoring of breaker failure by checking the disappearance of earth current after opening
- Remote control by communication channel: tripping or closing, load shedding with priority levels and load restoration

- Setting software compatible with Windows® 2000, XP, Vista and 7
- User interface with access to all protection functions
- Time stamping of internal events with 10ms resolution
- Time stamping of digital inputs with 10ms resolution
- Event recording: 250 locally recorded events, 200 saved in case of loss of auxiliary supply
- Recording of measurements and current setting group
- Local / remote events acknowledgment
- Disturbance recording according to Comtrade® format: storage of 4 recordings of 52 periods
- Disturbance recording forced by digital input, setting software or communication channel
- Closing function: adjustment of phase, earth, negative sequence current thresholds by external input
- Remote setting and reading of measurements, counters, alarms and parameter settings
- Remote reading of disturbance recording and event log
- Self-diagnosis: Memories, output relays, A/D converters, auxiliary supply, cycles of execution of software, hardware failure
- Test of wiring

Related equipment

• BA800 for ring CT 1500/1

Functional diagram





The specifications and drawings given are subject to change and are not binding unless confirmed by our specialists.

